

First Model Brown Bess Musket flint lock kit, Willits - 1746



#Lock-Bess-46 1746 lock parts, as-cast, with screws \$134.99

These early First Model Brown Bess lock parts are cast directly from original antique lock, by Willits - 1746. An advanced project, you must deburr, polish, drill, tap, harden, temper, and assemble the lock.

- #Lock-Bess-46-PI plate, *Willits - 1746*, with pan bridle \$14.99
- #Lock-Bess-46-Fr frizzen, as cast \$13.99
- #Lock-Bess-46-Fx frizzen screw, 8-32 thread \$ 2.29
- #Lock-Bess-46-Fs frizzen spring, as cast \$14.99
- #Lock-Bess-46-Fsx frizzen spring screw, 8-32 thread \$ 2.29
- #Lock-Bess-46-Co flint cock, 1.8" throw, undrilled \$14.99
- #Lock-Bess-46-Tj top jaw, 1.3 x 1.25" oval, stud at back \$ 5.99
- #Lock-Bess-1-Tjx top jaw screw, 5/16-18, waist head \$ 3.99
- #Lock-Bess-46-Tu tumbler, as cast \$ 8.99
- #Lock-Bess-46-Tx tumbler screw, 8-32 thread \$ 2.99
- #Lock-Bess-46-Br bridle, as cast, with integral pin \$ 7.99
- #Lock-Bess-46-Bx bridle screw, 8-32 thread \$ 2.29
- #Lock-Bess-46-Se sear, as cast \$ 7.99
- #Lock-Bess-46-Sx sear screw, 8-32 thread \$ 2.29
- #Lock-Bess-46-Ss sear spring, as cast, spring steel \$13.99
- #Lock-Bess-46-Ssx sear spring & main spring screw, 8-32 \$ 2.29
- #Lock-Bess-46-Ms mainspring, as cast, spring steel \$18.99

We recommend this book of clever home shop tempering techniques:

#Book-SVS *Simplified V Springs*, instructions \$ 5.99

We stock the 8-32 and 5/16-18 taps, and drill bits you may need.

